

3M[™] Formaldehyde/ **Organic Vapour Cartridge** Filter 6075, A1Form

Technical Data Sheet

Description

3M[™] Formaldehyde/Organic Vapour Filter 6075 is one 3M[™] 6000 series of gas/vapour cartridges. These are used in combination with 3M[™] Half and Full Face bayonet filter respirators.

Features

- 3M high performance activated carbon for effective filtration
- 3M[™] Bayonet Connection System ensures precise and secure locking
- Low profile and well balanced twin filter design
- Suitable for use with 3M[™] Half Face Respirators 6000/6500QL/7500 Series and Full Face Respirators 6000/FF-400 Series

Specifications

- Filter Rating: A1Form
- Provides protection against organic vapours (boiling point > 65°C) and Formaldehyde
- Weight: 95 gm per pair of filters

Hazards/Tasks

For protection when working with solvents and formaldehyde such as chemical processing, plastic production, fibreboard manufacturing, healthcare and laboratory work.

Note: Gas/vapour cartridges do not filter particulates. If there is exposure to particulates, including mists, use a combination of filters for protection. For example: fit the 3M[™]Particulate Filters 5925 (P2) and the 3M[™] Filter Retainer 501 over the gas/vapour cartridge to provide combined protection against dusts, mists and fumes as well as the rated gas/vapour (refer to picture below).







Materials

The following materials are used in this product:

- Filter Body Polystyrene
- Gas/Vapour Filter element Activated Carbon

Standards

- Complies with AS/NZS 1716:2012 (Respiratory protective devices).
- Use in accordance with AS/NZS 1715:2009 (Selection, use and maintenance of respiratory protective equipment).

Fitting Instructions

Only new, unused filters from their original packaging should be fitted to your facepiece. Ensure that both filters are of the same type and class.

- A. Align 6075 filter notch with facepiece 3M logo and push together.
- B. Turn filter 1/4 turn clockwise to stop. Discard and replace both filters at the same time.
- C. To remove filter, turn 1/4 turn anticlockwise.

Compatible facepieces











6000 Full Face

Disposal

Dispose in accordance with local and national regulations appropriate to the contaminants captured.

Low boiling point organic compounds are capable of migrating through 3M 6075 filters when not in use.

Technical Specifications

When selected and used in accordance with the standard (AS/NZS 1715) and for the contaminants specified, this filter is capable of providing the following protection:

- With a 3M 6000/6500QL/7500 Series Half Face Respirator: for organic vapour (boiling point > 65°C) and airborne concentrations up to 10 times the Workplace Exposure Standard (WES) or 1000 ppm, whichever is the lower.
- With a 3M Full Face Respirator: for organic vapour (boiling point > 65°C) and concentrations up to 50 x WES or 1000 ppm, whichever is the lower.
- Formaldehyde up to 10 x WES.

Warning and Limitations

Particular attention should be given to warning statements where indicated. Proper selection, fit, training, use and appropriate maintenance are essential in order for the product to help protect the wearer from certain airborne contaminants. Failure to follow all instructions on the use of these respiratory protection products and/or failure to properly wear the complete product during all periods of exposure may adversely affect the wearer's health, lead to severe or life threatening illness or permanent disability.

Always be sure that the complete product is:

- Suitable for the application;
- Fit tested and fitted correctly;
- Worn during all periods of exposure;
- Replaced when necessary.

For suitability and proper use follow local regulations, refer to all information supplied or contact an occupational hygienist, safety professional or 3M Customer Services -Australia 1300 363 565 - New Zealand 0800 252 627.

Use this respirator system strictly in accordance with all User Instructions:

- Do not submerge the filters in liquid.
- Do not use in atmospheres containing less than 19.5% oxygen. (3M definition. Individual countries may apply their own limits on oxygen deficiency. Seek advice if in doubt).
- Do not use these products in pure oxygen or oxygen enriched atmospheres.
- Do not use for respiratory protection against atmospheric contaminants and concentrations which have poor warning properties or are unknown or immediately dangerous to life and health (IDLH) or against contaminants/concentrations which generate high heats of reaction with chemical filters.
- Do not use in airborne concentrations above those specified in **Technical Specifications**.
- Leave the contaminated area immediately if:
- o Any part of the system becomes damaged.
- o Airflow to the face piece decreases or stops.
- o Breathing becomes difficult or increased breathing resistance occurs.

- o Dizziness or other distress occurs.
- o You smell or taste contaminants or irritation occurs.
- Never alter, modify or repair this device.
- These products do not contain components made from natural rubber latex.

NOTE: Save all user instructions for continuing reference.

Shelf Life, Storage and Transportation

Shelf life of the unopened product is five (5) years from date of manufacture when stored in temperature range -10° C to $+50^{\circ}$ C and at less than 90% relative humidity.

End of shelf life date is marked on the product packaging. Before initial use, always check that the product is within the stated shelf life. When storing or transporting this product use original packaging provided.

Storing the filters in an airtight container, will reduce exposure to the work environment and help prolong the life of the equipment

As per AS/NZS 1715:2009 Section 4.2.5.3, "All classes of gas filter shall be discarded no longer than six months after opening, irrespective of the number of periods of use".

Additional Information

3M™ Organic Vapour Monitor 3500+ and 3501+

3M[™] Monitors are simple and effective personal sampling badges. The monitor captures a wide range of airborne organic vapours, enabling a laboratory to analyse and identify the type and level of exposure to the worker.

The 3M[™] Organic Vapor Monitors 3501+

concentrations or short term exposure limit (STEL) sampling. It is designed to measure

time weighted-average (TWA) or short term

organic chemicals to demonstrate compliance

exposure limit (STEL) exposure to volatile

with Occupational Exposure Limits (OELs).

higher sampling rate badge is for low



3M™ Formaldehyde Monitor 3721+

This monitor is designed for measuring exposures to formaldehyde such as those in the chemical, pulp and paper, foundry and textiles industry. This monitor uses an impregnated filter to convert formaldehyde to a stable bisulfite addition product.

The airborne concentrations measured can be used as part of a risk management process to institute suitable controls, including assisting in determination of the type and service life of respiratory equipment appropriate to the contaminants (according to AS/NZS 1715).

For more information, please contact 3M and request a copy of the 3M[™] Organic Vapour Monitor 3500+, 3501+ and 3721+ Tech Data Sheet.



3M[™] Select & Service Life Software

3M have designed software to help you estimate how frequently certain 3M[™] Gas and Vapour Cartridges should be replaced. You can then use this information to establish a cartridge change schedule. You will firstly need information on the chemical contaminants in your working environment.

The exposure monitoring data may be entered into the 3M Service Life software at www.3M.com/sls to estimate the service life of 3M gas/vapour cartridges.

For more information contact your 3M representative.

Ordering Information



For assistance in determining 3M bayonet gas/vapour cartridge breakthrough and filter change schedules for certain gas/ vapour contaminants visit the free

3M Select and Service Life (SLS) Software | <u>www.3m.com/sls</u>

| | | Availa | Availability | | |
|------------|-------------|--------|--------------|---------|--|
| SAP ID | Legacy ID | AUS | NZ | Model # | Description |
| 7100098276 | UU006790370 | • | • | 6075 | 3M™ Formaldehyde/Organic Vapour Cartridge Filter 6075, A1 Form, 1 Pair/Pack, 30 Packs/Case. For Organic Vapours with >65 degrees celsius boiling point |
| | | | | | |

Important Notice

To the extent permitted by law, 3M shall not be liable for any loss or damage including any loss of business, loss of profits, or for any indirect, special, incidental or consequential loss or damage arising from reliance upon any information herein provided by 3M. Nothing in this statement will be deemed to exclude or restrict 3M's liability for death or personal injury arising from its negligence.



Technical Statement

Technical Information: The technical information, guidance, and other statements contained in this document or otherwise provided by 3M are based upon records, tests, or experience that 3M believes to be reliable, but the accuracy, completeness, and representative nature of such information is not guaranteed. Such information is intended for people with knowledge and technical skills sufficient to assess and apply their own informed judgment to the information. No license under any 3M or third party intellectual property rights is granted or implied with this information.

Product Selection and Use: Many factors beyond 3M's control and uniquely within user's knowledge and control can affect the use and performance of a 3M product in a particular application. As a result, customer is solely responsible for evaluating the product and determining whether it is appropriate and suitable for customer's application, including conducting a workplace hazard assessment and reviewing all applicable regulations and standards. Failure to properly evaluate, select, and use a 3M product in accordance with all applicable instructions and with appropriate safety equipment, or to meet all applicable safety regulations, may result in injury, sickness, death, and/ or harm to property.



3M Australia Pty Ltd Personal Safety Division Bldg A, 1 Rivett Road North Ryde NSW 2113 Customer Service: 1300 363 565 Email: 3msupport.safety.au@mmm.com Web: www.3M.com/au/ppesafety 3M New Zealand Ltd Personal Safety Division 94 Apollo Drive, Rosedale Auckland 0632 Customer Service: 0800 252 627 Email: 3msupport.safety.nz@mmm.com Web: www.3M.com/nz/ppesafety